

How to Disassemble a Tabit PAD Case



Step 1

Remove the Tabit Strap from the case

Step 2

Remove the silicon Protective Cover from the case

Step 3

Separate the Front and Back Covers by unlatching the fasteners. There are two fasteners on each side of the case

Step 4

After you have removed the Front Cover, remove the PAD and unplug the Y-Cable. After the PAD is removed from the Back Cover, flip the cover over to remove the Ingenico Device

Step 5

Using a Philips screwdriver, unscrew the four screws from the Ingenico Holder

Step 6

Remove the Ingenico Device from the back of the PAD

Step 7

Remove the Ingenico Device from the Device Holder, and unplug the Y-Cable from the Ingenico Device

Parts List



Front Case



Back Case



Protective Cover



Tabit Strap



Ingenico Device



Ingenico Holder



Y-Cable

Additional Resources

Additional resources available on the Tabit Knowledge Base:

- ◆ How to Assemble a Tabit PAD Case
- ◆ How to Change a Y-Cable on a Tabit PAD Case
- ◆ How to Pair an Existing Ingenico Device
- ◆ How to Pair a New Ingenico Device

If you need further assistance contact Tabit Support at support-us@tabit.cloud or 1-833-822-4887

Scan for Video

